

Test Program Manual (V0.1)

Location Based Service

Location Pathfinder. Devices & Services Development



L1/L2 RTK GNSS Receiver

Connecting Process


1. Install USB Driver (A)

- Driver can download at
- http://ascenkorea.net/?page_id=962

2. Install GNSS Viewer Test Program (B)

- Software can download at
- http://ascenkorea.net/?page_id=962

3. Connect USB cable at PC USB Port




<Pic1> Driver and Software download

Connecting Process

1. Comport (1)

2. Comport Open (2)



<Pic2> Comport Open

Connecting Process


1. Comport Setting (3)

- Comport can be checked at control panel of PC

2. Baud rate Setting (4)


- Set the baud rate ex)115,200bps
- Default 9,600bps

3. Confirm Button (5)



<Pic3> Comport Setting

- (6) Current Location
- (7) Satellite Location
- (8) Signal Level
- (9) NMEA Message
- (10) GNSS Information
- (11) Link Connect/Disconnect



Thank YOU!

Location Pathfinder. Devices & Services Development.

Customer's need is our mission!

AscenKorea